



## Držać praga sa četkicom za štok i prečku

Šifra      za profil      jed.mj.      Cijena      Pakiranje

### **za Aluplast Ideal 4000/70mm (štok)**

SH 94-002	140 002	70mm	par	20
SH 94-003	140 003	80mm	par	20

### **za Aluplast Ideal 2000/60mm (štok)**

SH 94-402	120 002	70mm	par	20
SH 94-403	120 003	80mm	par	20

### **za Aluplast Ideal 4000/70mm (prečka)**

MH 94-041	140 041	84mm	kom	20
MH 94-045	140 045	104mm	kom	20

### **za Aluplast Ideal 2000/60mm (prečka)**

MH 94-443	120 043	100mm	kom	20
MH 94-441	120 041	80mm	kom	20
	120042			

